

SPILL CONTROL

SPILL KITS ALLOW FOR IMMEDIATE CLEAN-UP OF SPILLS

Choice of oil or universal spill kits. Oil kits can handle oil and fuel spills on land or on water. Universal kits can handle acids, caustics (bases), common fluids

such as coolants, ethanol and pesticides, as well as solvents. Kits available for small spills such as in labs, to large spills in plants or on open water.



5-GALLON

UNIVERSAL - SORBENT CAP. - 5 GAL.

- 1 5-Gallon Polyethylene Pail
- 5 Universal Sorbent Socks (3" x 4') (SAH451)
- 1 Pair Nitrile Gloves (SAN478)
- 1 Pair Safety Goggles (SAN429)
- 2 Disposal Bags (26" x 36") (NG371)

Model No. SAK219



REPLACEMENT KIT

Model No. SG957

20-GALLON

OIL - SORBENT CAP. - 20 GAL.

- 1 30-Gallon Polyethylene Drum
- 4 Oil Sorbent Socks (3" x 10') (SAG316)
- 50 Oil Sorbent Pads (15" x 18") (SAP121)
- 1 Drain Cover (36" x 36" x 1/16") (SH104)
- 1 Repair Putty (SH105)
- 2 Pair Nitrile Gloves (SAN478)
- 5 Disposal Bags (26" x 36") (NG371)

Model No. SAK229



REPLACEMENT KIT

Model No. SG962

53-GALLON

OIL - SORBENT CAP. - 53 GAL.

- 1 Spill Control Locker (47" x 30" x 24")
- 4 Oil Sorbent Booms (5" x 10') (SB785)
- 100 Oil Sorbent Pads (15" x 18") (SAP121)
- 1 Drain Cover (36" x 36" x 1/16") (SH104)
- 1 Caution Tape (3" x 500') (SAD022)
- 1 Repair Putty (SH105)
- 2 Pair Nitrile Gloves (SAN478)
- 2 Pair Safety Goggles (SAN429)
- 2 Tyvek® Coveralls (SA170)
- 10 Disposal Bags (26" x 36") (NG371)

Model No. SAK235

W/CASTERS Model No. SAK237

REPLACEMENT KIT Model No. SG968



5-GALLON

OIL - SORBENT CAP. - 5 GAL.

- 1 5-Gallon Polyethylene Pail
- 1 Oil Sorbent Sock (3" x 10') (SAG196)
- 20 Oil Sorbent Pads (15" x 18") (SAP124)
- 1 Pair Nitrile Gloves (SAN478)
- 2 Disposal Bags (26" x 36") (NG371)

Model No. SAK221



REPLACEMENT KIT

Model No. SG958

21-GALLON

UNIVERSAL - SORBENT CAP. - 21 GAL.

- 1 30-Gallon Polyethylene Drum
- 4 Universal Sorbent Socks (3" x 10') (SAG197)
- 75 Universal Sorbent Pads (15" x 18") (SAP129)
- 1 Drain Cover (36" x 36" x 1/16") (SH104)
- 1 Caution Tape (3" x 500') (SAD022)
- 2 Pair Nitrile Gloves (SAN478)
- 2 Pair Safety Goggles (SAN429)
- 2 Tyvek® Coveralls (SA170)
- 5 Disposal Bags (26" x 36") (NG371)

Model No. SAK227



REPLACEMENT KIT

Model No. SG961

60-GALLON

UNIVERSAL - SORBENT CAP. - 60 GAL.

- 1 79-Gallon Polyethylene Overpack Drum
- 5 Universal Sorbent Socks (3" x 4') (SAH451)
- 5 Universal Sorbent Pillows (8" x 18") (SAG191)
- 4 Universal Sorbent Booms (5" x 10') (SB790)
- 50 Universal Sorbent Pads (15" x 18") (SAP129)
- 1 Universal Sorbent Roll (18" x 150') (SAJ782)
- 1 Drain Cover (36" x 36" x 1/16") (SH104)
- 1 Caution Tape (3" x 500') (SAD022)
- 2 Pair Nitrile Gloves (SAN478)
- 2 Pair Safety Goggles (SAN429)
- 2 Tyvek® Coveralls (SA170)
- 10 Disposal Bags (26" x 36") (NG371)

Model No. SAK239



W/CASTERS Model No. SAK241

REPLACEMENT KIT Model No. SG964

10-GALLON

UNIVERSAL - SORBENT CAP. - 10 GAL.

- 1 14-Gallon Polyethylene Pail
- 5 Universal Sorbent Socks (3" x 4') (SAH451)
- 5 Universal Sorbent Pillows (8" x 18") (SAG191)
- 1 Pair Nitrile Gloves (SAN478)
- 1 Pair Safety Goggles (SAN429)
- 3 Disposal Bags (26" x 36") (NG371)

Model No. SAK225



REPLACEMENT KIT

Model No. SG959

47-GALLON

UNIVERSAL - SORBENT CAP. - 47 GAL.

- 1 79-Gallon Polyethylene Overpack Drum
- 10 Universal Sorbent Socks (3" x 10') (SAG197)
- 8 Universal Sorbent Pillows (8" x 18") (SAG191)
- 100 Universal Sorbent Pads (15" x 18") (SAP129)
- 1 Drain Cover (36" x 36" x 1/16") (SH104)
- 1 Caution Tape (3" x 500') (SAD022)
- 2 Pair Nitrile Gloves (SAN478)
- 2 Pair Safety Goggles (SAN429)
- 2 Tyvek® Coveralls (SA170)
- 10 Disposal Bags (26" x 36") (NG371)

Model No. SAK247



W/CASTERS Model No. SAK249

REPLACEMENT KIT Model No. SG963

10-GALLON TRUCK SPILL KITS

CONTENTS FOR UNIVERSAL KITS:

- 10 Universal Sorbent Pads (15" x 18") (SAP129)
- 3 Universal Sorbent Socks (3" x 4') (SAH451)
- 2 Universal Sorbent Pillows (8" x 18") (SAG191)
- 1 Pair Nitrile Gloves (SAN478)
- 1 Pair Safety Goggles (SAN429)
- 1 Disposable Bag (26" x 36") (NG371)

Model No. Description

UNIVERSAL

- SAK261 Poly Zip Lock Bag
- SAG193 Replacement Kit

TRUCK SPILL KIT OPTIONS

- SH104 Neoprene Drain Cover
- SH105 Repair Putty

